# CS/B.Tech(EIE-NEW)/SEM-3/EI-301/2011-12 2011

# **ELECTRICAL MEASUREMENTS & INSTRUMENTS**

Time Allotted: 3 Hours

c)

Full Marks: 70

The figures in the margin indicate full marks.

Candidates are required to give their answers in their own words as far as practicable.

# GROUP - A

1.	(Multiple Choice Type Questions)					
	Choose the correct alternatives for any ten of the following					
						$10 \times 1 = 10$
	i)	Electrostatic-type instruments are primarily used as				
		a)	ammeters	b)	voltmeters	

- A set of reading has a wide range and therefore it has ii)
  - low precision a) b) high precision
  - low accuracy d) high accuracy.
- Current in the primary winding of CT depends on iii)
  - burden in the secondary winding of the a) transformer

d)

ohmmeters.

- b) load connected to the system in which the CT is being used for measurement
- both burden of the secondary and load connected c) to the system
- d) none of these.

wattmeters

- The main source of error in an accelerometer is the iv) presence of
  - gravitation force a) b) electromagnetic force
  - centrifugal force c) all of these. d)

- v) The high torque to weight ratio in an analog instrument indicates
  a) high friction loss
  b) low friction loss
  c) nothing as regards friction loss
  - d) none of these.
- vi) The secondary of a CT is
  - a) never left open circuited
  - b) never left short circuited
  - c) always kept open circuited
  - d) none of these.
- vii) The advantage of Varley loop tests over Murray loop test is
  - a) they can be used for localizing of short circuit faults
  - b) they can be used for localizing of earth faults
  - c) the loop resistance can be experimentally determined
  - d) their accuracy is higher.
- viii) Which instrument used for both ac and dc measurements?
  - a) Moving iron
- b) Electrodynamometer
- c) Electrostatic
- d) All of these.
- ix) Maxwell bridge can be used for measurement of inductance with
  - a) high Q factors
  - b) very low Q factors
  - c) medium Q factors
  - d) wide range of Q factor variations.
- x) A megger is used for measurement of
  - a) low valued resistances
  - b) medium valued resistances
  - c) high valued resistances
  - d) all of these.

- xi) Calibration in a *DC* potentiometer is done with the help of a standard cell of voltage
  - a) 1.5 volt

- b) 1.01864 volt
- c) 1.001864 volt
- d) 1.0864 volt.
- xii) The term 'threshold' used in instrumentation means
  - a) the smallest change in input which can be detected
  - b) a measure of linearity of the system
  - c) the smallest input which can be detected
  - d) a measure of precision of the system.

### GROUP - B

# (Short Answer Type Questions)

Answer any three of the following.  $3 \times$ 

 $3 \times 5 = 15$ 

- 2. Define precision and accuracy. Highly précised instrument need not be highly accurate. Explain. 3 + 2
- 3. The following 10 observations were recorded when measuring a voltage 41.7, 42.0, 41.8, 42.0, 42.1, 41.9, 42.0, 41.9, 42.5, 41.8 volt. Find
  - a) the Mean
  - b) the average deviation
  - c) standard deviation
  - d) probable error of one reading.
- 4. What are the main limitations of Wheatstone bridge? How are these limitations eliminated? Explain clearly. 1 + 4
- 5. Describe the Murray loop test method for localization of cable fault of short circuit type.
- 6. What are the advantages of instrument transformer over a shunt-on multiplier?

#### GROUP - C

## (Long Answer Type Questions)

Answer any *three* of the following.  $3 \times 15 = 45$ 

7. a) Explain the working principle of electrodynamometer type instrument.

3208(N) 3 [Turn over

# CS/B.Tech(EIE-NEW)/SEM-3/EI-301/2011-12



- b) A moving coil instrument gives a full scale deflection for a current of 20 mA with potential difference of 200 mV across it. Calculate
  - i) shunt required to use it as an ammeter to get range of 0-200 A.
  - ii) multiplier required to use it as a voltmeter of range 0-500 V.
- c) Mention some advantages and disadvantages of moving iron instrument. 5 + 5 + 5
- 8. a) Draw the equivalent circuit for the current transformer and hence find the expression of ratio error with a suitable phasor diagram.
  - b) Why does creeping occur in energymeter and how can it be eliminated? (3+5+2)+(2+3)
- 9. a) State the limitations of low resistance measurement. Describe the working of Kelvin double bridge with necessary calculation.
  - b) How insulation resistance can be measured using loss of charge method?
  - c) State the conditions for A.C. bridge balance.

(2+6)+5+2

- 10. a) Describe with circuit diagram how Drysdale or Gall potentiometer is used to measure A.C. voltage.
  - b) Draw the circuit diagram of *D.C.* potentiometer and explain how it works.
  - c) How can potentiometer be used for (i) calibration of voltmeter (ii) calibration of wattmeter? 5 + 5 + 5
- 11. Write short notes on any three of the following:  $3 \times 5$ 
  - a) Rectifier type instrument
  - b) Bath tub curve
  - c) Megger
  - d) Chi-square test
  - e) MTTF.